

Mask Cleaning Machine (GE-MCS1000)



Garam **ELECTRONICS CORP.**

Head Office

723 Shingil-7 Dong, Yeongdeungpo-ku, Seoul, 150-057 Korea
TEL : 82-2-782-8771, Fax : 82-2-785-2577, E-Mail : garam@gamec.com
Web : www.gamec.com

China Factory

#11, Hengshan Road, ETZDZ Yantai, Shandong, 264006 China
TEL : 86-535-639-5190, Fax : 86-535-639-5177, E-Mail : garam@garam.cn

Mask Cleaning Machine (GE-MCS1000)

Basic Specifications

1. Bath Configuration

Bath 1 <Supply & Drain>

Bath 2 < Chemical Cleansing >

- Chemical: DF-6000 / 40L

- AIR Bubble

- Ultrasonic Waves: 48 KHz/ 800W

- Heating: 2Kw

- Temp: Max. 40° +/- 1°

Bath 3 < Rinse>

- DI water rinse

- Over Flow

- Air Bubble

- Ultrasonic Waves: 48 KHz/800W

Bath 4< Shower>

- DI water Shower < shower Pump>

2. Equipment Operation

Bath 1

Set the Basket → Start Button → 90° Rotation →

Bath 2

DF-6000 Cleansing (For Set Time) →

Bath 3

Rinse (For Set Time) →

Bath 4

Shower (For Set Time) → Finish

3. Power

AC200V, 50/60 Hz, 3 Phases

4. Size

2000 * 1600 * 1800 mm

5. Weight

700Kg

6. Utility

DI water

Exhaust Duct

Air: 5Kg/cm²